

## ▶ Quick Start Guide

- ▶ Package Contents
- ▶ Compatible Smartphones
  - ▶ Before Using Scanner
  - ▶ Hardware Features
- ▶ Using Smartphone Scanner
  - ▶ Specifications



# Smartphone Scanner

## Package Contents

- Smartphone Scanner
- Slide/Negative Holder
- Combo 3" x 5" and 4"x6" Photo Holder
- iPhone 4/4S Cradle
- iPhone 5 Cradle
- Galaxy SII Cradle
- Galaxy SIII Cradle
- 4 AA Batteries
- USB Cable
- Quick Start Guide

## Compatible Smartphones

Smartphone Scanner is compatible with the following devices (not included in the package):

- iPhone 4
- iPhone 4S
- iPhone 5
- Galaxy SII
- Galaxy SIII

Note:

iPhone 4, iPhone 4S and iPhone 5 are trademark of Apple Inc., registered in many countries.

Galaxy SII and Galaxy SIII are trademark of Samsung Electronics Co., Ltd., registered in many countries.

## Before Using Scanner

To use with iPhone


Open the Apple Store on your iPhone and download the iPhotojet app.

To use with Galaxy S

Open the Play Store on your Galaxy S and download the iPhotojet app.















## Hardware Features



1. Power
2. Smartphone Cradle Exchange
3. Smartphone Camera Hole
4. Battery Power
5. USB Power
6. Slide/Negative Holder Insert.
7. Photo Holder Insert.

## Using Smartphone Scanner

1. Power on Smartphone Scanner. (Make sure to power from either the battery or USB.)
2. Place Smartphone in the appropriate Smartphone Cradle with the screen facing up. Place Cradle on top of the Smartphone Cradle Exchange of the main scanner unit.
3. Place the slide, negative, or photo into the appropriate holder.
4. Insert the holder into the scanner. (Make sure only one holder is inserted at one time.)
5. Open the iPhotojet app. Touch to select one of the scan type to proceed.
6. Touch Camera icon  to capture. While on the preview screen, touch Use  to continue to the next step or Retake  for another shot.
7. On the screen message pop-up: "Would you like to further adjust EV/color performance", touch Yes  to enter the settings. (Touch Brightness  or Color  icon to switch between the two settings. Once ready, touch Do  to exit to main screen). Touch No  to exit to main screen.
8. While the captured image is on the main screen, by touching: Save  to keep it in your smartphone Album; Email  to e-mail out to someone; Facebook  to upload it to Facebook. (Please note that selecting Email or Facebook will not save to your Smartphone Album.)
9. Touch the Cross  sign to complete the capture. Continue the next shot or exit the app.

## Specifications

- Dimensions (W x D x H): 245 x125 x 158 mm (9.65" x 4.92" x 6.22")
- Weight:0.49 kg (1.08lb)